


CONVI2C



JP settings

	JP1	JP2	LDOIN	LDOOUT	Note
1. H_VDD ext, L_VDD ext:	-	-	-	-	LDO is not mounted
2. H_VDD ext, L_VDD int:	-	mnt	H_VDD	L_VDD	LDO must be mounted (S_VDD voltage)
3. H_VDD int, S_VDD ext:	mnt	-	>H_VDD	H_VDD	LDO must be mounted (M_VDD voltage, LDOIN is greater then M_VDD)

[illegible]